

DATE: _____

Item	Description	YES	NO	NA	Remarks	Inspected By (Initials)
➤Daily						
1	Inspect oil level and top up if needed					
2	Check coolant level in radiator/expansion tank					
3	Verify fuel level in day tank and main tank					
4	Look for oil, coolant, or fuel leaks around the unit					
5	Ensure battery charger is active and charging					
6	Confirm control panel shows no alarms or faults					
➤Weekly						
1	Inspect belts and hoses for wear or tension issues					
2	Check air intake system and clean filters if clogged					
3	Drain fuel/water separator to remove accumulated water					
4	Inspect battery terminals for corrosion or loose cables					
5	Conduct warm up and cool down cycles (5 minutes each)					
➤Monthly						
1	Perform an operational test under load (min. 30% load for 30-60 minutes)					
2	Monitor governor performance (frequency stability at 60Hz)					
3	Inspect Exhaust system for soot leaks or damage					
4	Ensure enclosure louvers are clear of debris					
➤Quarterly						
1	Replace oil filter and change oil					
2	Replace fuel filters (primary and secondary)					
3	Clean or replace air filters					

4	Inspect alternator connections and tighten if necessary				
5	Test automatic transfer switch (ATS) operation				
➤Annual					
1	Flush and replace coolant				
2	Perform battery load test and replace if weak				
3	Inspect and clean generator windings				
4	Check control panel calibration and update firmware if required				
5	Conduct a full system load bank test to verify rated capacity				

PREPARED BY:

Engr. Roan Paul B. Gallegos/ Elmer Esteban
Building Maintenance
FCLGC

INSPECTED BY:

Martin Naimés/ Crispin De Gracia
BM Technician
FCLGC